

Strong Butter

INGREDIENTS

1 oz cannabis
16 oz butter

DIRECTIONS

SLOW COOKER (recommended)

- Rinse or blanch your cannabis to clean
- Put butter in slow cooker
- Break in cannabis with your fingers
- Cook on low for 24-32 hours -or- break up over 3 days.
- Strain with fine metal sieve or cheesecloth -or-

STOVETOP

- Rinse or blanch your cannabis to clean
- Pour vegetable glycerin in saucepan
- Break in cannabis with your fingers
- Cook on low-med (don't boil)
- Stir every 90 minutes
- Keep in pot overnight & run again in AM for 8 hours- repeat for 3 days
- Strain after with fine metal sieve or cheesecloth

Can be combined with unmedicated butter to reduce intensity of dose.
Freeze if storing.

COOK TIME

24-32 hours

SERVES

16 oz

RECIPE BY



Mary V

RECIPE BY



Nebber